



THERMOFORMING COMPONENTS ARCIL




SECTIONS

 Click on this logo for more information



-  Piston
-  Pistion pad & Inner retaining piston
-  Piston screw & Knurled wheel
-  Guide & Entry plate
-  Entry blade & Forming punch
-  Dosing cutting valve & Dosing block
-  Sealing block / Retaining rod / Heating Block / Piston end /Piston rod
-  Insolating Plates
-  Base retaining block / Roller / Pulley shaft / Pulley
-  Rebuilt cutting unit & Rebuilt bedknife unit
-  Lateral cutting unit blade
-  Cutting unit blade
-  Cutting unit star punch
-  Belleville washer / Spring / Spring support
-  Top retaining plate / Retaining bolt / Shoulder bolt
-  Deflector / Sprocket wheel / Drive roller / Date coding unit



PISTON



Piston (Left)
UMAR-P250046
P250046



Piston (Right)
UMAR-P250047
P250047




Piston (Left)
UMAR-P245083
P245083




Piston (Right)
UMAR-P245082
P245082



Piston (Left)
UMAR-P274320
P274320



Piston (Right)
UMAR-P274321
P274321



Piston (Left)
UMAR-P173036
P173036



Piston (Right)
UMAR-P173027
P173027




Piston (Left)
UMAR-P245083
P245083




Piston (Right)
UMAR-P145082
P145082

PISTON PAD


INNER RETAINING PISTON




Piston Pad
UMAR-P363743
P363743



Piston Pad
UMAR-P350048
P350048




Piston Pad
UMAR-P4110140
UMAR-P470172
P4110140
P470172



Piston Pad
UMAR-P363743
P363743



Piston Pad
UMAR-P473037
P473037



Inner Retaining Piston
UMAR-P467953



Inner Retaining Piston
UMAR-P437444



Inner Retaining Piston
UMAR-P450057


PISTON SCREW KNURLED WHEEL




Piston Screw C163
UMAR-P431266



Piston Screw
UMAR-P467126




Hollow Screw
UMAR-P467955



Knurled Wheel
UMAR-P437963

GUIDE ENTRY PLATE



Guide (universal)
UMAR-P491766



Guide (universal)
UMAR-P491765



Entry Plate (Right)
UMAR-P174341



Entry Plate (Left)
UMAR-P174340



Entry Plate (Right)
UMAR-P1104589



Entry Plate (Left)
UMAR-P1104588

ENTRY BLADE FORMING PUNCH




Entry Blade
(Right)
UMAR-P391232




Entry Blade
(Left)
UMAR-P391233



Forming Punch
UMAR-P335472



Forming Punch
UMAR-P3121123



Forming Punch
UMAR-P341453

DOSING CUTTING VALVE DOSING BLOCK




Dosing Cutting Valve
UMAR-P148039
UMAR-P376594



Dosing Cutting Valve
UMAR-P189145
UMAR-P5126350



Dosing Cutting Valve
UMAR-P199150



Dosing Block
UMAR-P23503-08



Dosing Block
UMAR-P23503-018
UMAR-P23503-019



Dosing Block
UMAR-P23503-026
UMAR-P23503-027

SEALING BLOCK / RETAINING ROD HEATING BLOCK / PISTON END PISTON ROD



Sealing Block
UMAR-P546359
UMAR-P546360
UMAR-P5104838
UMAR-P5104840




Retaining Rod
UMAR-P324353



Heating Block
UMAR-P541455
UMAR-P519396
UMAR-P17590
Improved




Piston End
UMAR-P496668




Piston Rod
UMAR-P393084

INSOLATING PLATES




Insolating Plates

UMAR-P338393
UMAR-P224348
UMAR-P341448
UMAR-P174305
Improved



Insolating Plates


UMAR-P379186
UMAR-P379187
UMAR-P379188
UMAR-P379189
UMAR-P379190
Improved




Insolating Plates

UMAR-P388220
UMAR-P388221
UMAR-P388222
UMAR-P388223
UMAR-P388224
Improved


BASE RETAINING BLOCK / ROLLER PULLEY SHAFT / PULLEY



Base Retaining Block
UM P/N : 0125-006-01-01



Roller
UM P/N : 0155-004-04-02
Improved



Pulley Shaft




Pulley
UMAR-P17634

REBUILT CUTTING UNIT

REBUILT BEDKNIFE UNIT




Refurbished Cutting Unit



Refurbished Bedknife Unit


LATERAL CUTTING UNIT BLADE



Lateral Cutting Unit
Blade (Left)
UMAR-P268430




Complementary Lateral
Cutting Unit Blade (Left)
UMAR-P272925




Lateral Cutting Unit
Blade (Right)
UMAR-P268431




Complementary Lateral
Cutting Unit Blade (Right)
UMAR-P272926



Lateral Cutting Unit
Blade (Left)
UMAR-P230696



Lateral Cutting Unit
Blade (Right)
UMAR-P230697



Lateral Cutting Unit
Blade (Left)
UMAR-P230702



Lateral Cutting Unit
Blade (Right)
UMAR-P230701

CUTTING UNIT BLADE




Cutting Unit Blade
(56.75mm)
UMAR-P368429



Cutting Unit Blade
(56.75mm)
UMAR-P368428



Cutting Unit Blade
(51.75mm)
UMAR-P368427



Cutting Unit Blade
(51.75mm)
UMAR-P330704



Cutting Unit Blade
(56.75mm)
UMAR-P330705



Cutting Unit Blade
(56.75mm)
UMAR-P330706

CUTTING UNIT STAR PUNCH



Cutting Unit Star Punch
UMAR-P368411



Cutting Unit Star Punch
UMAR-P230703



Cutting Unit Star Punch

BELLEVILLE WASHER / SPRING SPRING SUPPORT



Belleville Washer
UMAR-7834



Spring Support
UMAR-6953




Spring
UMAR-C668423




Spring
UMAR-1979


TOP RETAINING PLATE RETAINING BOLT / SHOULDER BOLT



Top Retaining Plate
UMAR-P441712



Top Retaining Plate
UMAR-P441713



Top Retaining Plate
UMAR-P468432



Top Retaining Plate
UMAR-P465433



Retaining Bolt
UMAR-P470750



Retaining Bolt
UMAR-P428865




Shoulder Bolt M8x50mm
UMAR-P429947



Shoulder Bolt M8x36mm
UMAR-P468422

DEFLECTOR/ SPROCKET WHEEL DRIVE ROLLER / DATE CODING UNIT




Deflector (universal)
UMAR-P3102761
UMAR-P3102760




Sprocket Wheel Ø10-1/2"
UMAR-BAP-128794




Labelling Drive Roller



Date Coding Unit: Pivot Pin
UMAR-P440660



Date Coding Unit: Pivot (Left)
UMAR-P440658



Date Coding Unit: Pivot (Right)
UMAR-P440657